

MAGNETIC/DIGITAL VEHICLE SPEED SENSOR
MAGNETIC VEHICLE SPEED SIGNAL (+)/DIGITAL VEHICLE SPEED SIGNAL
MAGNETIC VEHICLE SPEED SIGNAL (–)
<23
TELEFLEX MORSE ACCELERATOR PEDAL ASSEMBLY
WILLIAMS ACCELERATOR PEDAL ASSEMBLY
APS1
APS2
ACCELERATOR POSITION #1 +5 VOLT SUPPLY
SENSOR SUPPLY #4
<27
ACCELERATOR POSITION #1 SIGNAL
ACCELERATOR POSITION #1 RETURN
<28
ACCELERATOR POSITION #2 +5 VOLT SUPPLY
SENSOR SUPPLY #5
<26
ACCELERATOR POSITION #2 SIGNAL
ACCELERATOR POSITION #2 RETURN
SENSOR RETURN
<22
REMOTE ACCELERATOR PEDAL/ LEVER ASSEMBLY
REMOTE ACCELERATOR PEDAL/LEVER +5 VOLT SUPPLY
REMOTE ACCELERATOR PEDAL/LEVER SIGNAL
REMOTE ACCELERATOR PEDAL/LEVER RETURN
ENGINE COOLANT LEVEL SENSOR
ENGINE COOLANT LEVEL +5 VOLT SUPPLY (ONLY FOR 3 WIRE SENSORS)
ENGINE COOLANT LEVEL SIGNAL
ENGINE COOLANT LEVEL RETURN
OEM PRESSURE SENSOR
OEM PRESSURE +5 VOLT SUPPLY
OEM PRESSURE SIGNAL
OEM PRESSURE RETURN
ENGINE BRAKE SELECTOR SIGNAL #1
ENGINE BRAKE LEVEL SWITCH
ENGINE BRAKE SELECTOR SIGNAL #2
ENGINE BRAKE ON/OFF SWITCH
VGT BRAKE ON/OFF SWITCH
VGT BRAKE SELECTOR SIGNAL
CLUTCH/ENGINE PROTECTION OVERRIDE SWITCH
CLUTCH/ENGINE PROTECTION OVERRIDE SWITCH SIGNAL
SERVICE BRAKE POSITION SWITCH
SERVICE BRAKE POSITION SWITCH SIGNAL
CRUISE CONTROL/PTO SET RESUME SELECT SWITCH
CRUISE CONTROL/PTO RESUME/ACCELERATE/INCREMENT SWITCH SIGNAL
CRUISE CONTROL/PTO SET/COAST/DECREMENT SWITCH SIGNAL
CRUISE CONTROL/PTO ON/OFF SWITCH
CRUISE CONTROL/PTO ON/OFF SWITCH SIGNAL
AIR CONDITIONER PRESSURE SWITCH
AIR CONDITIONER PRESSURE SWITCH/FAN CONTROL SWITCH SIGNAL
FAN CONTROL SWITCH
ACCELERATOR INTERLOCK/ENGINE TORQUE LIMIT SWITCH
ACCELERATOR INTERLOCK/ENGINE TORQUE LIMIT SWITCH SIGNAL
AFTERTREATMENT DIESEL PARTICULATE FILTER REGENERATION SWITCH/DIAGNOSTIC TEST MODE SWITCH
AFTERTREATMENT DIESEL PARTICULATE FILTER REGENERATION SWITCH/ DIAGNOSTIC TEST MODE SWITCH SIGNAL
MAXIMUM OPERATING SPEED/GOVERNOR TYPE SWITCH
MAXIMUM OPERATING SPEED/GOVERNOR TYPE SWITCH SIGNAL
REMOTE ACCELERATOR ON/OFF SWITCH
REMOTE ACCELERATOR ON/OFF SWITCH SIGNAL
REMOTE PTO ON/OFF SWITCH
REMOTE PTO ON/OFF SWITCH SIGNAL
REAR AXLE RATIO SWITCH
REAR AXLE RATIO SWITCH SIGNAL
TACHOGRAPH
TACHOGRAPH SIGNAL
TACHOMETER
SWITCH RETURN
TACHOMETER OUTPUT SIGNAL
<41
<12
HIGH EXHAUST SYSTEM TEMPERATURE LAMP SIGNAL
<58