





Factory lift pump. unplug connector, install relay on power feed to this pump, pins 85 &86 from two wires. An aftermarket relay, fog lamp relay will suite.

Electric

FASS Pump, connect to 12v ignition switched source. The harness will have to be modified, as its designed to connect to a Dodge.
Pin 30 Chassis Battery power, fused.
Pin 85, ignition power.
Pin 86, ground.
Pin 87, Fass pump Power.