

TO MAIN HARNESS

BATTERY DISCONNECT SW

EMER START R — #14 WHT/YEL
 EMER START S — #14 WHT/RED
 GROUND — #14 WHT
 IGN POWER INPUT — #14 WHT/RED
 SLIDE ROOM POWER — #10 WHT/RED

BLK — COM
 RED — ON
 ORG — OFF
 BLU

12V POWER DIST. CENTER 2006

NATIONAL RV INC.

P/N 130670 (REV 7-08-04)

