



* INDICATES EQUIPMENT OPTIONS
USED ON SOME MODELS



LAY-OUT

VEC - CONNECTOR

LOC No	FUNCTION	FROM
1	VEC-1 IGN SW POWER	20 A FUSE
2	VEC-2 BATT TRANSMISSION	15 A FUSE
3	GROUND TRANSMISSION	GND
4	TCM41 NEUTRAL START	NSR86
5	ISS ENGINE START	NSR30
6		



WIRING DIAGRAM

P/N 03215174 Rev A

CUMMINS ISL & ISC ENGINE - VEHICLE ELECTRONICS