


SWITCH IS TO BE SPDT,  
(ON)-OFF-(ON) WITH FUNTION-ON  
INDICATOR AND LOCKING FUNCTION.

REV.	UNIT	DESCRIPTION OF CHANGE	BY	DATE
--	-	-----	---	--/--/--

T-POST IN FRONT  
DIST. PANEL  
COMPARTMENT





B+ FROM  
INST. PNL.  
18 ORANGE

HOUSE  
SWITCHED 12V  
FRONT DIST.  
PANEL

HOUSE NON-  
SWITCHED 12V  
FRONT DIST.  
PANEL

BATTERY  
CUT OFF



← 18 TINNED  
BARE COPPER

18 WHITE

TO REAR INT.  
FUSE PANEL

USAGE: ADMIRAL, MONARCH, TRAVELER, VACATIONER,  
LAPALMA, CAYMAN, NEPTUNE, KNIGHT, AMBASSADOR, TREK,  
CHEETAH, SAHARA, SANTIAM, ENDEAVOR, DIPLOMAT, SCEPTER,  
CAMELOT, WINDSOR, GAZELLE, AND IMPERIAL.