

<u>LED LIGHTS</u>

PROGRAM MODE

INDIVIDUAL ADJUST

EXTEND TAUGHT

RETRACT TAUGHT

EXTEND

RETRACT


TURN ON MODULE TO PROGRAM

1) PRESS PROGRAM BUTTON.

2) REVIEW STATUS ON LED LIGHTS:

LED LIGHTS:

PROGRAM MODE LED (ON)
INDIVIDUAL ADJUST(ON)
EXTEND TAUGHT LED (ON)
RETRACT TAUGHT LED(ON)




LED LIGHTS
PROGRAM MODE
INDIVIDUAL ADJUST
EXTEND TAUGHT
RETRACT TAUGHT
EXTEND
RETRACT

REMOVING PRESET SOFT-LIMITS

- 1) PRESS AND HOLD PROGRAM BUTTON.
- 2) PRESS MOTOR B RETRACT
- RELEASE PROGRAM & MOT/B RETRACT(RETRACT LED TAUGHT TURNS OFF)
- 4) PRESS AND HOLD PROGRAM BUTTON.
- 5) PRESS MOTOR B EXTEND BUTTON
- 6) RELEASE PROGRAM & MOT/B EXTEND(RETRACT LED TAUGHT TURNS OFF)

LED LIGHTS:

PROGRAM MODE LED (ON)	
INDIVIDUAL ADJUST(ON)	
EXTEND TAUGHT LED (OFF)	
RETRACT TAUGHT LED(OFF)	



LED LIGHTS
PROGRAM MODE
INDIVIDUAL ADJUST
EXTEND TAUGHT
RETRACT TAUGHT
EXTEND
RETRACT

REPROGRAMMING SOFT-LIMITS

- 1) PRESS MOTOR A&B EXTEND TO FULL EXTEND (CHECK FOR GOOD INSIDE SEAL)
- 2) HOLD PROGRAM AND DEPRESS MOTOR B EXTEND ONCE (EXTEND TAUGHT)
- 3) PRESS MOTOR A&B RETRACT TO FULL RETRACT(CHECK S/O FLUSH TO SIDEWALL)
- 4) HOLD PROGRAM AND DEPRESS MOTOR B RETRACT ONCE (RETRACT TAUGHT)
- 5) PRESS AND RELEASE PROGRAM BUTTON (OUT OF PROGRAM ALL LIGHTS OFF)
- 6) TEST SLIDEOUT FOR OPERATION.

EXTEND/RETRACT PROGRAMMED	PROGRAM MODE OFF ROOM PROGRAMMED
PROGRAM MODE LED (ON)	PROGRAM MODE LED (OFF)
INDIVIDUAL ADJUST(ON)	INDIVIDUAL ADJUST(OFF)
EXTEND TAUGHT LED (ON)	EXTEND TAUGHT LED (OFF)
RETRACT TAUGHT LED(ON)	RETRACT TAUGHT LED(OFF)